

Procedures for Installing an RFID Sticker

The HeadlightSticker™ RFID transponder is our top shelf RFID transponder, purpose-built for external vehicular application and identification.

HeadlightSticker™ installation are simple enough. But remember that stickers are designed to break upon removal: meaning you have to get it right the first time!

1. Clean your headlight before applying RFID sticker

Use window cleaner and a microfiber cloth (to prevent scratching the headlight).

Make sure the headlight is dry before proceeding with the installation



Remember!

- Place stickers horizontally
- Sticker faces RFID antenna (rule of thumb)
- Wait 24 hours before power washing



2. Tag Handling

- Place sticker face down on a flat surface
- Hold sticker down with fingertip/nail
- Peel the backing away from the sticker



3. Installation

Hold the HeadlightSticker™ (horizontally) by the edges, press down, and smooth out the tag to remove air bubbles.

- Mount the tag at least 2 inches away from vehicle metal.
- If possible while maintaining the 2 inch spacing, do not place the tag directly in front of the bulb.
- All other things being equal, mounting the tag in front of the high beam is preferable to the low beam.

The Don'ts & Avoids

- Once on, don't lift up – no more adjusting
- Avoid vehicle metal
- Having Issues? Don't remove the sticker – Call for help first!



Need More Help?

Get Connected with your certified HLS Dealer